



**MANDRINI
ATTACCO MAS403/BT
E DOPPIO CONTATTO**

TOOLHOLDERS BT/MAS403
AND DUAL DRIVE

6D



MANDRINI ATTACCO MAS403/BT E DOPPIO CONTATTO


TOOLHOLDERS BT/MAS403 AND DUAL DRIVE



MANDRINI IDRAULICI
HYDRAULIC CHUCKS

6D


Mandrini idraulici
Hydraulic chucks



BT30

CODICE	FAM	D	FORMA	H	A	EUR
BT30.H50.8.HD6	5	6	AD	50.8	26	
BT30.H50.8.HD8		8		50.8	28	
BT30.H50.8.HD10		10		50.8	30	
BT30.H50.8.HD12		12		50.8	32	
BT30.H85.HD12		12		85	26.5	
BT30.H90.HD14		14		90	34	
BT30.H90.HD16		16		90	38	
BT30.H90.HD18		18		90	40	
BT30.H90.HD20		20		90	42	


Mandrini idraulici con il passaggio del refrigerante
Coolant hydraulic chucks



BTB40

CODICE	FAM	D	FORMA	H	A	EUR
BTB40.H90.HD.6	5	6	AD+B	90	26	
BTB40.H140.HD6		6		140	26	
BTB40.H90.HD.8		8		90	28	
BTB40.H140.HD.8		8		140	28	
BTB40.H90.HD10		10		90	30	
BTB40.H140.HD.10		10		140	30	
BTB40.H90.HD.12		12		90	32	
BTB40.H140.HD.12		12		140	32	
BTB40.H90.HD.14		14		90	34	
BTB40.H140.HD.14		14		140	34	
BTB40.H90.HD.16		16		90	38	
BTB40.H140.HD.16		16		140	38	
BTB40.H90.HD.18		18		90	40	
BTB40.H140.HD.18		18		140	40	
BTB40.H90.HD.20		20		90	42	
BTB40.H140.HD.20		20		140	42	
BTB40.H90.HD.25		25		90	55	
BTB40.H140.HD.25		25		140	55	
BTB40.H90.HD.32		32		90	63	
BTB40.H140.HD.32		32		140	63	

Mandrii idraulici con il passaggio del refrigerante
 Coolant hydraulic chucks


BTB50

CODICE	FAM	D	FORMA	H	A	EUR
BTB50.H90.HD.6	5	6	AD+B	90	26	
BTB50.H140.HD.6		140		26		
BTB50.H90.HD.8		8		90	28	
BTB50.H140.HD.8		8		140	28	
BTB50.H90.HD.10		10		90	30	
BTB50.H140.HD.10		10		140	30	
BTB50.H90.HD.12		12		90	32	
BTB50.H140.HD.12		12		140	32	
BTB50.H90.HD.14		14		90	34	
BTB50.H140.HD.14		14		140	34	
BTB50.H90.HD.16		16		90	38	
BTB50.H140.HD.16		16		140	38	
BTB50.H90.HD.18		18		90	40	
BTB50.H140.HD.18		18		140	40	
BTB50.H90.HD.20		20		90	42	
BTB50.H140.HD.20		20		140	42	
BTB50.H90.HD.25		25		90	55	
BTB50.H140.HD.25		25		140	55	
BTB50.H90.HD.32		32		90	63	
BTB50.H140.HD.32		32		140	63	