



**MANDRINI  
ATTACCO MAS403/BT  
E DOPPIO CONTATTO**

TOOLHOLDERS BT/MAS403  
AND DUAL DRIVE

**6P**



# MANDRINI ATTACCO MAS403/BT E DOPPIO CONTATTO


TOOLHOLDERS BT/MAS403 AND DUAL DRIVE



**MANDRINI PORTAALESATORI FLOTTANTI**  
FLOATING REAMER HOLDERS

**6P**


**Portapinze con regolazione radiale e passaggio del refrigerante**  
Coolant radial adjustable collet chucks



**BT40 / 50**


CODICE	FAM	CAP	PINZA	FORMA	FLOT	H	A	EUR
BTB40.ERC16.L93RG	1	1 ÷ 10	ER16	AD	$\pm 1 \text{ mm}$	93	28	
BTB40.ERC20.L95RG		1 ÷ 14	ER20			95	34	
BTB40.ERC25.L96RG		1 ÷ 20	ER25			96	42	
BTB40.ERC32.L97RG		2 ÷ 22	ER32			97	50	
BTB40.ERC40.L131RG		3 ÷ 30	ER40			131	63	
BTB50.ERC16.L103RG		1 ÷ 10	ER16			103	28	
BTB50.ERC20.L105RG		1 ÷ 14	ER20			105	34	
BTB50.ERC25.L106RG		1 ÷ 20	ER25			106	42	
BTB50.ERC32.L107RG		2 ÷ 22	ER32			107	50	
BTB50.ERC40.L141RG		3 ÷ 30	ER40			141	63	

**Centratura regolabile 0,1mm**  
*Adjustable runout 0,1mm*



Allentare le viti **B** e regolare la centratura tramite le viti **A**.  
*Loosen screws **B** and use screws **A** for radial adjustment.*


**Portapinze extra corto**  
Shortly Collet chucks



**BT40 / 50**

CODICE	FAM	CAP	RPM	FORMA	H	EUR
BT40.H29.ERC32A	1	2 ÷ 22	12.000	AD	29	

**Portapinze extra corto con passaggio del refrigerante**  
Coolant Shortly Collet chucks



**BTB40 / 50**

CODICE	FAM	CAP	RPM	FORMA	H	EUR
BTB40.H50.ERC32A	1	2 ÷ 22	12.000	AD	50	
BTB50.H40.ERC32A					40	