



**MANDRINI ATTACCO HSK  
FORMA - A / C / E / F**

TOOLHOLDERS  
HKS FORM - A / C / E / F

**9A-2**



# MANDRINI ATTACCO HSK FORMA - A / C / E / F

## TOOLHOLDERS HKS FORM - A / C / E / F




**SYNCRO PORTAPINZE**  
SYNCHROFER ER TOOLHOLDERS



**SYNCRO CAMBIO RAPIDO**  
QUICK CHANGE SYNCHROFER TOOLHOLDERS

**9A-2**


**SYER - Mandrini Portapinzze a micro-compensazione assiale in compressione e trazione**  
SYER - Synchrofer er tapholders



**HSK-A / 63 / 100**

CODICE	CONO	T	C	CAP	ER	A	L	EUR
HSK63A-SYER16M-L89	HSK A 63	0.5	0.5	1 ÷ 10	16M	22	89	
HSK63A-SYER16-L89				1 ÷ 10	16	28	89	
HSK63A-SYER20-L90				1 ÷ 14	20	34	90	
HSK63A-SYER25-L94				1 ÷ 20	25	42	94	
HSK63A-SYER32-L105				2 ÷ 22	32	50	105	
HSK63A-SYER40-L133.5				3 ÷ 30	40	63	133.5	
HSK100A-SYER16M-L97	HSK A100	0.5	0.5	1 ÷ 10	16M	22	97	
HSK100A-SYER16-L96				1 ÷ 10	16	28	96	
HSK100A-SYER20-L97				1 ÷ 14	20	34	97	
HSK100A-SYER25-L101				1 ÷ 20	25	42	101	
HSK100A-SYER32-L110				2 ÷ 22	32	50	110	
HSK100A-SYER40-L133				3 ÷ 30	40	63	133	

**SY- Mandrini Portabussole a micro-compensazione assiale in compressione e trazione**  
SY - Synchrofer tapholders



**HSK-A / 63 / 100**

CODICE	CONO	T	C	CAP	X	A	D1	L	EUR
HSK63A-SY1-L99	HSK A 63	0.5	0.5	M3 ÷ M12	19	32	35	99	
HSK63A-SY2-L114				M8 ÷ M20	31	50	45	114	
HSK100A-SY1-L108	HSK A100			M3 ÷ M12	19	32	35	108	
HSK100A-SY2-L120				M8 ÷ M20	31	50	45	120	